NORTHWESTERN UNIVERSITY	
PROJECT NAME	FOR:
IOB #	ISSUED: 03/29/2017

SECTION 09 6513 - RESILIENT BASE AND ACCESSORIES

PART 1 - GENERAL

#### 1.1 RELATED DOCUMENTS

A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 01 Specification Sections, apply to this Section.

# 1.2 SUMMARY

- A. Section Includes:
  - 1. Resilient base.
  - 2. Resilient stair accessories.
  - 3. Resilient molding accessories.
- 1.3 ACTIOLT D Tw -9.482 -19i0 Tc 0 Tw 1.398 0 Td ( )Tj -0.T700m522.6-12.3d ( )Tj .3R11.398c4lm5221bH2 <<0 Tc

#### B. LEED Submittals:

- 1. Product Data for Credit IEQ 4.1: For adhesives, documentation including printed statement of VOC content.
- 2. Product Data for Credit IEQ 4.3: For adhesives, documentation including printed statement of VOC content.
- 3. Product Data for Credit IEQ 4.3: For resilient stair accessories, documentation from an independent testing agency indicating compliance with the FloorScore standard.
- C. Samples: For each exposed product and for each color and texture specified, not less than 12 inches (300 mm) long.
- D. Samples for Initial Selection: For each type of product indicated.
- E. Samples for Verification: For each type of product indicated and for each color, texture, and pattern required in manufacturer's standard-size Samples, but not less than 12 inches (300 mm) long.
- F. Product Schedule: For resilient base and accessory products. Use same designations indicated on Drawings.

# 1.4 MAINTENANCE MATERIAL SUBMITTALS

A. Furnish extra materials that match products installed and that are packaged with protective covering for storage and identified with labels describing contents.

NORTHWESTERN UNIVERSITY	
PROJECT NAME	FOR:
JOB #	ISSUED: 03/29/2017

NORTHWESTERN UNIVERSITY	
PROJECT NAME	FOR:
JOB #	ISSUED: 03/29/2017

## 2.4 RUBBER MOLDING ACCESSORY

- A. Manufacturers: Subject to compliance with requirements, provide products by one of the following:
  - 1. Armstrong World Industries, Inc.
  - 2. Burke Mercer Flooring Products; a division of Burke Industries Inc.
  - 3. Johnsonite; a Tarkett company.
  - 4. Roppe Corporation, USA.
- B. Description: Rubber [stair-tread nosing] [carpet edge for glue-down applications] [nosing for carpet] [nosing for resilient flooring] [reducer strip for resilient flooring] [joiner for tile and carpet] [transition strips].
- C. Profile and Dimensions: [As indicated] < Insert profile and dimensions>.
- D. Locations: Provide rubber molding accessories in areas indicated on the drawings.
- E. Colors and Patterns: As selected by Architect from full range of industry colors.

## 2.5 INSTALLATION MATERIALS

- A. Trowelable Leveling and Patching Compounds: Latex-modified, portland cement based or blended hydraulic-cement-based formulation provided or approved by resilient-product manufacturer for applications indicated.
- B. Adhesives: Water-

#### 

- E. Do not stretch resilient base during installation.
- F. On masonry surfaces or other similar irregular substrates, fill voids along top edge of resilient base with manufacturer's recommended adhesive filler material.
- G. Preformed Corners: Install preformed corners before installing straight pieces.

# 3.4 RESILIENT ACCESSORY INSTALLATION

- A. Comply with manufacturer's written instructions for installing resilient accessories.
- B. Resilient Stair Accessories:
  - 1. Use stair-tread-nose filler to fill nosing substrates that do not conform to tread contours.
  - 2. Tightly adhere to substrates throughout length of each piece.
  - 3. For treads installed as separate, equal-length units, install to produce a flush joint between units.
- C. Resilient Molding Accessories: Butt to adjacent materials and tightly adhere to substrates throughout length of each piece. Install reducer strips at edges of floor covering that would otherwise be exposed.

# 3.5 CLEANING AND PROTECTION

- A. Comply with manufacturer's written instructions for cleaning and protecting resilient products.
- B. Perform the following operations immediately after completing resilient-product installation:
  - 1. Remove adhesive and other blemishes from exposed surfaces.
  - 2. Sweep and vacuum horizontal surfaces thoroughly.
  - 3. Damp-mop horizontal surfaces to remove marks and soil.

C.